

In order to use MutekH, you may need to:

- Have a working cross-compiler
- Understand the BuildSystem
- Try the Quick start guide for SoCLib platforms, which covers the (non-soclib) EMU target in the beginning